

For the problem that Wonderwheel cannot select the icon, the attachment is the latest MCU software, and the following is the software upgrade steps, which may solve the problem.

(1) Download the software **APM32F030.bin** to Windows.

(2) Insert the TF card into the card reader, then insert the card reader into Windows, and format the TF card on the computer, the file format is FAT32. A 32GB TF card is recommended.

(3) Copy the software **APM32F030.bin** to the TF card. Please note that you cannot add or modify characters to the name of the software. If the software name contains characters such as (1) or (2), the upgrade will be unsuccessful.

(4) Pull out the card reader, take out the TF card, power on the Carpuride device, and then insert the TF card into the Carpuride device, the startup screen will be automatically updated.